

DCM1 Utility tool read me

Cloud DCM-1 Utility Tool

This tool can be used to configure or backup a Cloud DCM-1 mixer.

The tool works best with DCM-1 software version 1.05 and above. V1.04 and below do not have certain features such as the ability to read Labels.

If your DCM-1 has version 1.04 or below is recommended that you update to version 1.05 available from the Cloud Website www.cloud.co.uk

To check current version:

- Put DCM-1 in installer mode
- Select SYSTEM page
- Press the NEXT FUNCTION button until the screen reads "Update Firmware"
- Leave it untouched for a few seconds; the display will first show the help page and then the version page.

Before updating a DCM-1 in an existing installation it is recommended that you back up the settings using this utility tool.

NB make a note of any labels, a backup of version 1.04 will not have label information.

To use this tool unpack the zip file and copy the .exe file to a suitable place on the hard drive of your PC.

The tool can be used in standalone mode to create a set of parameters which can be saved and loaded to a DCM-1 at a later time.

To load or read a DCM-1 the PC should be connected to the DCM-1 via a straight through serial cable. Most USB to serial cables will work. The DCM-1 should be set to 9600 baud (The default). The PORT menu of the tool is used to select the COM port to communicate.

A DCM-1 can be backed up by pressing the "Read DCM-1" button. It takes a few minutes to complete. Once done the settings can be saved to file. NB the installer key is not read.

Use the "Send All" button to send the complete set of parameters in the tool (except installer key) to the DCM-1.

The INPUTS and OUTPUTS pages offer the option to send setting for a single input/ output or all inputs/outputs.

The INSTALLER KEY page allows the installer key to be changed.

The SYSTEM page sets up system wide settings.

NB it is not possible to use the tool to change the DCM-1s RS232 setting.